




C10



AD2



X2

X6

C11

Time out



AD3

Детали со стороны TOP

кроме X1, X2, X6

90T

AD8



S/SF

key1

ve+

ADV

mic

TOP

R1/3
ADV
GND
key2
S/SF
R2/2



KEY1

R1/5
R1/1

Mic R2/1

GND



KEY3

Automat



KEY5

TOP

